

X-O Primer Aerosol

DESCRIPTION

Superior interior/exterior rust preventative Primer, spray at any angle, comfort spray tip.

ENVIRONMENTAL STATEMENT

Contains no CFC's which deplete the ozone layer



X-OP Rust Primer

TYPE: Medium oil alkyd, interior/exterior Paint and Primer in One

VOC/MIR

VOC & MIR COMPLIANT

Maximum 65% VOC & 1.4 pw MIR for gloss

and satin enamels.

GLOSS AT 60º

Primers: 5-20

1220 PERCENT SOLIDS BY WEIGHT 20.5%

COLORS

1280P Gray Primer 1267P Red Metal Primer

1220P White Metal Primer

Product Features

- •Fast Drying
- •Popular decorative colors
- •Spray at any angle comfort tip
- •Lasts Longer

FLASH POINT

< 20º F.

RECOMMENDED USE:

Rust-preventative coating for all interior and exterior metal surfaces. Also for wood, masonry and handcrafts. Do not use on Styrofoam, ceramic tiles or marble.

DRY TIME: Dry to touch 20 minutes. Tack free 3-4 hours. Recoat within one hour. High humidity or low temperature may increase dry time.

DISPOSAL: Dispose of aerosol container and unused contents in accordance with local, state and federal regulations. Do not burn, incinerate, puncture or place aerosol container in home garbage compactor.

CLEAN UP: Never stick sharp objects into the opening at the top of the can. For wet film, use mineral spirits. For dry film, use paint stripper, toluol or acetone.

DISPOSAL: To recycle or properly dispose of paint in your community, call 1-800-CLEANUP (USA only) or go to www.Earth911.org.

STORAGE: Do not store at temperatures above 120°F (50°C). Protect unused product from freezing.

APPLICATION METHODS

- •Before spraying, shake can for 2 minutes after ball within begins to rattle and occasionally during use.
- •Hold can 10" to 16" (25 to 40 cm) away from the surface and apply several thin coats a few minutes apart rather than one heavy coat, slightly overlapping each stroke.
- Keep can in motion while spraying.
- Recoat within one hour.

SURFACE PREP:

- •Remove all grease, oil, dirt, wax and rust scale from surface.
- •On new clean surface no primer is necessary. For rusty metal surfaces prime with X-O Rust Primer.
- •New galvanized surfaces must weather 6 months before priming.
- •Use with adequate ventilation.

WARNINGS

Contains propane, acetone and aromatic solvents. Extremely flammable. Storage and handling: Level-3 Aerosols.