



## Rental One High Traffic Pre-Treat

**DESCRIPTION:** Rental High Traffic Pre-Treatment penetrates and lifts seated soil. Helps raise trampled carpet. Great for hallways and entranceways and any high traffic zone.

### ROC-3 Formula

Percent solids by weight: 4 to 5.5 %  
Viscosity: Water thin  
Weight per US Gallon: 8.4 +/- 0.1lb

### Product Features:

- Apply directly to affected carpet

**RECOMMENDED USE:** Use on hallways, stairs, entranceways and other heavily soiled areas.

**TIPS:** Vacuum carpet thoroughly. Before cleaning carpet, test product in a small hidden place for colorfastness or shrinkage. When using any product on stain-resistant carpeting, check manufacturer's recommendations for use. Do not mix with bleach or any other household chemicals.

**DISPOSAL:** Use up or give away excess product . Contains surfactants. Do not reuse container. Empty container may be recycled or placed in trash.

**HANDLING & STORAGE:** Avoid extreme temperatures. Store in a cool, dry area. Close container after each use. If frozen, thaw and mix before use.

---

**APPLICATION :** A pre-conditioner that loosens soil and dirt in traffic lanes such as hallways, stairs, entranceways and other heavily soiled areas. Pre-spray in conjunction with carpet extraction or use as a spot remove for beverage, food, grease, ink and paint stains. Meets or exceeds carpet manufacturer's specification for cleaning stain-resistant carpets. Not recommended for use on upholstery. Designed for use with all carpet extraction machines.

---

### PRE-SPRAY TRAFFIC LANES:

- Spray on any heavily soiled area – avoid over wetting carpet
- Allow to work on an area for 2 to 5 minutes
- Allow carpet to dry. Drying time can be reduced by using a blower or several fans

### •SPOT REMOVAL:

- Act as quickly as possible. The longer a spill is neglected the more difficult the removal process
- Spray directly on area as soon as stain is detected
- Allow to work for 1 - 3 minutes
- Blot area with a clean white towel, always working from the edge of the spill to the center
- DO NOT SCRUB THE AREA!
- Allow area to dry. To speed drying, apply a ½ inch layer of white paper towels to area and weigh down with a flat, heavy object
- If stain is not completely removed, repeat procedure