

EASYCARE™

Exterior Latex Redwood Stain – LRW-1



DESCRIPTION

Painter's Select Specialty Exterior Flat Latex Redwood Stain

LRW-1 Formula Analysis:

Resin Type=Acrylic Latex

Penetrating Stain

Weight per Gallon=8.60 lbs/gal

Percent Solids by Weight=8.94%

Percent Solids by Volume=7.17%

Viscosity=75-80 KU

VOC= Less than 50 g/l

PRODUCT FEATURES

- Solid color finish ideal for fencing & wood siding
- Dries quickly to a flat finish
- Economical & easy to apply
- Easy soap and water clean-up

RECOMMENDED USE

Exterior above ground natural wood such as fencing, siding, shakes & shingles. NOT TO BE USED ON DECKS, PATIOS AND ANY AREA WALKED ON.

DRY TIME, THINNING & TINTING: Dries thoroughly within 4 hours. Allow 12-15 hours between coats. High humidity or low temperatures may increase dry time. DO NOT THIN. **COVERAGE:** 250-400 sq. ft. (33 square meters) per gallon (3.78L) first coat depending on the porosity of the wood.

CLEAN UP & DISPOSAL: Wash tools with warm water and soap immediately after application. Properly dispose of all soiled rags. Protect unused portion from freezing. To recycle or properly dispose of paint in your community, call 1-800-CLEANUP (USA only) or visit www.Earth911.org.

APPLICATION METHOD

- DO NOT APPLY TO DECKS
- Apply only to properly prepared and cleaned wood surfaces.
- On redwood, cedar, rough fir or pine siding an exterior oil Based Primer must be applied to prevent bleeding into the topcoat.
- On non-porous surfaces apply only one coat, as two coats may result in a high sheen finish.
- On very porous or severely weathered wood two coats may necessary.
- Do not apply if rain or dew is expected within 48 hrs or if outside temperature could drop below 50° F
- Do not apply in hot sun.
- Stir thoroughly before and during use.
- Intermix all containers for uniform color.
- Use a premium brush or pad applicator.
- A pump-up sprayer or roller can be used to apply the stain but back brushing with a brush is necessary to get the stain into the wood.
- DO NOT OVER APPLY.
- Spread well, do not puddle or accumulate on wood surface.
- Moving left to right, apply to two or three boards at a time leaving a “wet edge” to prevent lapping.
- Saturate end grain.