

# EASycARE

## Premium Décor Appliance Epoxy



### DESCRIPTION

Superior interior/exterior appliance epoxy spray at any angle, comfort spray tip. Formulated for household appliances and tools. Produces a uniform, hard finish that resists dirt and stains.

### ENVIRONMENTAL STATEMENT

Contains no CFC's which deplete the ozone layer

- **Premium Décor Epoxy**
- **TYPE:** Epoxy
- VOC & MIR COMPLIANT
- Maximum 65% VOC & 0.95 pw MIR for gloss
- and satin enamels.
- **GLOSS AT 60°**
- Gloss Enamels: 80 MIN
- **PERCENT SOLIDS BY WEIGHT:** 17.69%
- PDS-1544 + - 2

### PRODUCT FEATURES

- Fast Drying
- Lasts Longer
- Resists Chipping

### COLORS & BASES

- PD-1538 White
- PD-1539 Black
- PD-1544 Almond
- PD-1553 Stainless

### FLASH POINT

< 20° F.

### RECOMMENDED USE

Appliances, interior sealed wood, metal and tools. Do not use on Styrofoam, ceramic tiles or marble. Do not use on ovens or inside dryers.

**DRY TIME:** Dry to touch in 10-25 minutes. Tack free in 3-5 hours. Recoat within one hour. High humidity or low temperature may increase dry time.

**DISPOSAL:** Dispose of aerosol container and unused contents in accordance with local, state and federal regulations. Do not burn, incinerate, puncture or place aerosol container in home garbage compactor. To recycle or properly dispose of paint in your community, call 1-800-CLEANUP (USA only)

**CLEAN UP:** Never stick sharp objects into the opening at the top of the can. For wet film, use mineral spirits. For dry film, use paint stripper, toluol or acetone.

**STORAGE:** Do not store at temperatures above 120°F (50°C). Protect unused product from freezing.

### APPLICATION METHOD

- Before spraying, shake can for two minutes after ball within begins to rattle  
Shake can occasionally during use
- Hold can 10" to 18" (25 to 45 cm) away from the surface
- For a smooth finish, spray in a sweeping motion
- To avoid runs and drips, apply several thin coats rather than one heavy coat

### SURFACE PREP

- Remove all grease, oil, dirt, wax and rust scale from surface.
- On new, bare and rusty surfaces Premium Décor or XOP Primer is recommended.
- New galvanized surfaces must weather 6 months before priming.
- Use with adequate ventilation.

### WARNINGS

Contains propane, acetone and aromatic solvents. Extremely flammable. Storage and handling: Level-3 Aerosols.