

EASYCARE.

Interior/Exterior Oil Stain Blocking Primer

DESCRIPTION

Interior/Exterior Oil-Based Stain Blocking Primer/Sealer great for blocking stains on drywall, paneling, wood, masonry and stucco. Blocks smoke or water damage.

• SRO-1 FORMULA ANALYSIS

- Resin Type-Medium Oil
- Sheen/Type Finish:
- 3-5 @60° / Primer
- Weight per Gallon = 10.82 lbs. \pm .2 %
- Percent Solids by Weight = 49.0% \pm 2 %
- Percent Solids by Volume = 34.0 % \pm 2 %
- Viscosity Range = 95-105 KU
- V.O.C. = Less than 100 g/L
- MPI 136



PRODUCT FEATURES

- Blocking and sealing stains
- Sticks to glossy surfaces

COLORS

SRO-1 White

RECOMMENDED USE

New or unsealed interior drywall, non-staining wood, plaster, brick, stone and concrete surfaces.

THINNING: Use as is.

DRY TIME: Dries overnight. High humidity may increase dry time.

Low temperature or high humidity may increase dry time.

COVERAGE: Average coverage 300-400 sq. ft. per gallon.

CLEAN UP: Use mineral spirits.

DISPOSAL: Full: Give remaining product to neighbors or community organization. Partially full: (If state or local regulations allow) Pour residue into absorbent material. When dry, dispose of in trash for pick up. Empty: This container may be accepted in a recycling program.

STORAGE: Protect unused product from freezing.

APPLICATION METHOD

- Stir thoroughly before and during use.
- Do not apply over a surface that has not been properly prepared.
- Use product when surface and air temperature are between 50°F – 90°F.
- Do not over spread.
- Use a high quality 3/8 inch nap roller cover or nylon/polyester brush.
- Allow new masonry to cure at least 30 days before coating.

SURFACE PREP

- Remove dirt, grease ,wax and soap residue.
- Dull glossy areas with sandpaper.
- Patch cracks and holes then sand smooth when dry..
- New plaster must be properly cured before priming.