

# EASYCARE.

## Interior Water-Based Vapor Barrier Primer PRP-1

### DESCRIPTION

This product is specially formulated to reduce moisture vapor transmission through the walls of your home. By maintaining humidity in your home during the winter, your home will be more comfortable. Designed for use on all interior walls made of drywall or plaster.



### PRP-1 FORMULA ANALYSIS

Resin Type-Styrene Butadiene Latex  
Sheen/Type Finish:

1-4 @60° / Primer

Weight per Gallon = 10.56 lbs. ±2%

Percent Solids by Weight = 41.0 % ±2%

Percent Solids by Volume = 27.0 % ±2%

Viscosity Range = 84-88 KU

V.O.C. = Less than 200 g/L

### PRODUCT FEATURES

- Forms vapor barrier inside the home
- Helps lower heating bills
- Helps insulation work more effectively
- Outstanding sealing properties
- Vapor transmission rate is <1

### COLORS

PRP-1 White

### RECOMMENDED USE

All interior walls and ceiling surfaces such as drywall, plaster, wood, stone & concrete. Ideal for use

over drywall mud and tape joint compound. This product meets moisture vapor barrier specification when tested under ASTM D-1653-91A and ASTM E-96.

**THINNING:** DO NOT THIN.

**DRY TIME:** Dries in 1 hour. Recoat in 4 hours. Low temperature or high humidity may increase dry time.

**COVERAGE:** Average coverage 400 sq. ft. per gallon.

**CLEAN UP:** Tools, drips and spills should be cleaned with soap and warm water immediately. Properly dispose of all soiled rags.

**DISPOSAL:** Full: Give remaining product to neighbors or community organization. Partially full: (If state or local regulations allow) Pour residue into absorbent material. When dry, dispose of in trash for pick up. Empty: this container may be accepted in a recycling program.

**STORAGE:** Protect unused product from freezing.

### APPLICATION METHOD

- Stir thoroughly before and during use.
- Do not apply over a surface that has not been properly prepared.
- Use product when surface and air temperature are between 50°F – 90°F.
- Do not over spread.
- Use a high quality 3/8 inch nap roller cover or nylon/polyester brush.
- If applying by roller, roll from dry area into the wet using firm crisscrossing strokes. Finish with long ceiling to floor strokes in one direction.
- Paint the ceiling first, then the walls.
- Allow new masonry to cure at least 30 days before coating.

### SURFACE PREP

- Remove loose paint, wash off dirt and grease with detergent. Allow to thoroughly dry.
- Scuff-sand and dull glossy surfaces.
- Patch cracks and spot prime with this product.